



FR Pour plus d'informations / **EN** For more information / **DE** Weitere Informationen / **NL** Voor meer informatie / **ES** Para más información / **PT** Para mais informações / **IT** Per ulteriori informazioni / **EL** Για περισσότερες πληροφορίες / **TR** Daha fazla bilgi için / **CS** Vice informací naleznete zde / **SK** Pre viac informáci / **HU** További információk / **PL** Więcej informacji można znaleźć / **ET** Lisateave / **LT** Norėdami daugiau informacijos / **LV** Vairāk informācijas / **BG** За повече информация / **RO** Pentru informații suplimentare / **SL** Več informacij / **HR** Za više informacija / **BS** Za više informacija / **SR** Za više informacija / **RU** Для получения дополнительной информации / **UK** Для отримання докладніших відомостей / **CN** 获取更多信息 / **HK** 更多信息 / **KO** 더 자세한 정보는 아래 웹사이트에서 확인할 수 있습니다 / **AR** للمزيد من المعلومات / **FA** برای کسب اطلاعات بیشتر / **FI** Lisätietoja / **NO** For mer informasjon / **DA** For mere information / **SU** För mer information.

 Handheld	ECO 
 Handstick	Up to 35 min. 24 min.

The diagram illustrates the process of emptying the dust container in eight steps:

1. Press the dust container release button (marked with a blue circle and the word "MAX") to open the dust container.
2. Pull the dust container out of the tool.
3. Lift the dust container lid (indicated by a blue arrow pointing up).
4. Push the dust container lid down (indicated by a blue arrow pointing down).
5. Pour the dust into a trash can (indicated by a blue arrow pointing down).
6. Push the dust container lid down (indicated by a blue arrow pointing down).
7. Push the dust container back into the tool (indicated by a blue arrow pointing down).
8. Close the dust container lid (indicated by a blue arrow pointing down).

3a.

12h

3b.

24h

3c. 99% FILTRATION

NEW ZR009005

3d. EASY WASH

NEW ZR009006

4.

CLICK SLIDE

5.

NO

6.

OK NO YES

FR	Guide de l'utilisateur	RO	Ghidul utilizatorului
EN	User's guide	SL	Navodila za uporabnika
DE	Bedienungsanleitung	HR	Upute za uporabu
NL	Gebruiksaanwijzing	BS	Upute za upotrebu
ES	Guía del usuario	SR	Uputstvo za upotrebu
PT	Guia de utilização	RU	Руководство пользователя
IT	Manuale d'uso	UK	Посібник користувача
EL	Οδηγός χρήσης	CN	用户指南
TR	Kullanım kılavuzu	HK	用戶指南
CS	Návod k použití	KO	사용자 가이드
SK	Používateľská príručka	AR	دليل الاستعمال
HU	Használati útmutató	FA	راهنمای کاربر
PL	Instrukcja obsługi	FI	Käyttöopas
ET	Kasutusjuhend	NO	Brukermanual
LT	Naudotojo vadovas	DA	Bruger manual
LV	Lietošanas pamācība	SU	Användarmanual
BG	Ръководство на потребителя		

1. 2. 3. 4. 5. 6.

XFORCE FLEX RH96/TY96/EO96